



HP Pavilion zd8000 RAM Replacement

Written By: Allie Menard



INTRODUCTION

Removing the RAM from this device is straightforward and requires little disassembly.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)



PARTS:

- [PC2-5300 1 GB RAM Chip](#) (1)
- [PC2-5300 512 MB RAM Chip](#) (1)

Step 1 — Battery



- Slide the battery release latch towards you.

Step 2



- Pull up on the battery to remove it.

Step 3 — RAM



- Loosen the Phillips screw labeled 'ram' and lift the cover.

Step 4



- Locate the green RAM card and find the metal tabs securing the card.
- Push outwards on the two tabs to release the card.

Step 5



- Carefully slide the card out at an upward angle away from the slot.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 09:46:52 AM.